



Lock Better. Live Better.

# Amazon Alexa User Manual



## **NOTICE:**


1. You should add lock to the AUSLOCK APP;
2. You should connect the Gateway;
3. You should connect the Alexa to your phone.

## 1. Pair Your Lock


### 1.1 Download and Register




- 1) Android mobile phone, please scan the left QR code as above
- 2) Apple mobile phone, please scan the right QR code as above
- 3) You can also search for AUSLOCK in the APP store or Google play for download
- 4) Register a new account (phone number or email) or login with an existing account.
- 5) Touch the locks screen to light up the buttons, on App click "+ Add Lock"
- 6) The lock nearby will appear on the phone screen, Click "+"
- 7) Re name the lock
- 8) The lock is added successful




1-1




1-2




1-3




1-4



1-5



1-6






1-7

## 2.Pair Your Gateway

### Light Status



When the gateway is powered on:


-  Light flashes alternately in red and blue: Stand-by mode, ready for pairing
-  Blue light: Working mode
-  Red light: Network failure

### Pair the Gateway with APP


1 Activate the APP




2 Press "☰"



4 Select [G2]



5 Plug in the gateway and power it on, while the light flashes alternately in red and blue



3 Select [Gateway]



6 Press "+" sign



7 Add Gateway



8 Select the network and fill in the password



9 Add complete

⚠ Notice: If times out, please power off and try it again.

### 3. Download and Sign up of Amazon Alexa

#### 3.1 Search directly in the APP store

#### 3.2 Sign up (you can log in directly if you already have an account with Alexa)

amazon alexa

Sign-In

[Forgot password?](#)

Email (phone for mobile accounts)

Amazon password

Show password

**SIGN-IN**

[New to Amazon?](#)

**CREATE A NEW AMAZON ACCOUNT**

© 1999-2019 Amazon.com, Inc. or its affiliates

3-2-1

amazon alexa

Create account

Your name

Your e-mail address

Create a password

*i* Passwords must be at least 6 characters.

Show password

**CREATE YOUR AMAZON ACCOUNT**

"By creating an account, you agree to Amazon's Conditions of Use and Privacy Policy."

[Already have an account?](#)


**SIGN-IN NOW**

© 1999-2019 Amazon.com, Inc. or its affiliates


3-2-2

## 4. Enable Alexa Skill: ScienerSmart

### 4.1 Choose the "Skills & Games" option to get into the skill store




4-1-1




4-1-2

## 4.2 Input the "ScienerSmart" in the search bar





4-2-1





4-2-2

## 4.3 Click ScierSmart in the search result and click "ENABLE TO USE"



4-3-1




4-3-2

## 4.4 Input your sciener account for authorization

< Link Account ×

Done 🔒 api.sciener.cn ↻




**Authorize**

After authorizing, sciener will be able to manage your devices

< > 📄 ⌚

**4-4-1**

## 4.5 When the authorization is complete, return to the Amazon Alexa APP to click the “Discover device” or cancel



amazon alexa



ScienersSmart has been successfully linked.


What to do next:

→ Close this window to discover smart-home devices you can control with Alexa.



### Discover Devices

Smart Home devices must be discovered before they can be used with Alexa.




4-5-1




4-5-2


4.6 If you choose discover device you can find nearby devices and add it. If the search fails, you don't need to worry. If you choose cancel please do the following:




4-6-1




4-6-2




4-6-3




4-6-4



4-6-5




4-6-6




4-6-7




4-6-8




4-6-9




4-6-10




4-6-11




4-6-12




4-6-13



4-6-14




4-6-15




4-6-16


## 4.7 Add lock to Alexa




4-7-1




4-7-2




4-7-3



4-7-4



4-7-5




4-7-6



4-7-7




4-7-8




4-7-9


4.7 When the configuration is complete, please click the “HOME” door lock you just added click the three-point icon in the upper right corner, add click the “unlock by voice” button to enter the configuration page.



4-7-1



4-7-2




4-7-3


**4.8 Set the voice confirmation code and then verify the account.**  
**Then the function of “Unlock by voice” will be automatically enable**  
**and the configuration is finished!**

**You can start use it!**


**For example:** Say to Alexa :Alexa, unlock Home!



**4-8-1**



**4-8-2**



**4-8-3**