

240V LED DOWNLIGHT

Installation Instructions

Important for installation

- It is recommended that light kits supplied with a power plug are installed by simply plugging them into a professionally installed Australian power outlet. Where required, have a qualified electrician install accessible in-ceiling socket outlets.
- Alternatively, the product can be hard-wired by a qualified electrician according to AS/NZ3000:2007 and as per Figure 1
- Make sure the electricity supply is disconnected before any installation
- This product is not suitable for explosive environment, and unless specifically IP rated, is not suitable for a damp environment
- Do not install with other electrical devices on the same circuit as the LED luminaire such as ceiling or exhaust fans
- Do not mix different luminaires on the same circuit – combine only with matching luminaires
- Only install with the accompanying supplied LED driver. Do not connect to any different driver or transformer.
- If dimmable, to achieve intended performance It is recommended that only LED specific dimmers are used with this light
- The light must be installed in locations and in conditions as described in Figure 2

Figure 1 – Hard wire diagram





Figure 2 – Manufacturer's recommended minimum installation clearances



- Subject to a 3 year standard Manufacturer Warranty
- Warranty terms available at www.RenovatorStore.com.au>Returns
- Modification of any component, or non-adherence to "Important for Installation" points above will void warranty